
SHX Fan

User's Manual

References included in this manual BJ-EX41





Safety Precautions

- Please read the whole manual before you start.
- The product should always be used under adult supervision.
- The SHX fan is designed to create a sensory effect, it is not designed for direct use with users.



- It must be disconnected from the power supply before cleaning.
- If you find any damage or any material is missing when you unpack the product, please contact BJ Adaptaciones. It is recommended to keep the boxes for the duration of the warranty period in case you need to use them again.

1. Introduction to the product

Turn on the fan in any SHX scene when you want to recreate wind or coolness and enjoy the feeling.

2. Product components







BJ-234 Enabler Socket+

3. Before you start: conditions for correct operation

- The fan should only be used where there is a power socket.
- The fan can be wall mounted. Wall attachments are not included.

4. Product use

- The SHX fan is ready to interact with the SHX room.
- It is only necessary to connect the power supply and this in turn to the BJ-234 Enabler Socket+
- The fan is switched on and off from the Control SHX software and via the various control elements.

5. Maintenance and cleaning


- Clean the surface of the SHX Fan regularly to ensure the correct performance of the device.
- It must be disconnected from the power supply before cleaning.
- Clean using soapy water and a soft cloth (wrung out).
- Never use chemical or abrasive products for cleaning.
- Thoroughly dry the surface and wait one hour to connect to the power supply.

6. Additional information

If the Socket+ configuration is lost:

- See enclosed product manual
- The configuration of the socket+ for use with the BJ SHX control software must be as follows:





Action Act: code 28 Action ON: code 74 Action OFF: code 58

Yellow wheel: position 6 - 15 seconds

Blue wheel: position 0

Warranty

Within the legal warranty period we agree to rectify for free by repairing or replacing defects in the product derived from defective materials or manufacturing defects.

Any unauthorised alteration or modifications to the product will void this warranty.

Contacting technical and after-sales service

If you find any damage or any material is missing please contact our technical service for assistance.

Any damage or breakage caused during transport must be notified within three days of receipt.



